

Snap Foot for Atlas Bipods

Installation & Use

Installation:

- 1.) Use a bullet tip or pointed tool to depress the detent button on the factory foot and slide it out the end of the leg
- 2.) Insert Atlas Adapter Socket into leg, and align the detent button so it pops through the hole in the side of the leg
- 3.) Insert the factory rubber foot into the included Atlas Rubber Foot Adapter as you would install it in the factory bipod leg socket, so it can be used along with the KNS foot options.

Use:

- Install the desired foot by pressing its spherical end straight down into the socket on the leg, making sure to align the socket notches with the cross pin if present. Remove the foot by pulling straight out; not by prying it against the side of the socket.
- Occasionally lubricate the socket O-ring with a small amount of Vaseline or white lithium grease. Lip balm will even work in a pinch
- If the O-ring ever needs replacement, it can be pulled out with a small hooked wire, and the included replacement pressed back into the groove in the socket