

Snap Foot for Magpul Bipods

Installation & Use

Installation:

- 1.) Holding one leg in a vise or V-block, use a punch to drive out the spring pin holding the factory rubber foot, so it can be removed and replaced with the KNS adapter socket
- 2.) Align Magpul Adapter Socket cross-hole with the leg, secure with the included 1/8" X 5/8" spring pin

Use:

- Install the desired foot by pressing its spherical end straight down into the socket on the leg, making sure to align the socket notches with the cross pin if present. Remove the foot by pulling straight out; not by prying it against the side of the socket
- Occasionally lubricate the socket O-ring with a small amount of Vaseline or white lithium grease. Lip balm will even work in a pinch
- If the O-ring ever needs replacement, it can be pulled out with a small hooked wire, and the included replacement pressed back into the groove in the socket