

LC CHARGER INSTALL AND REMOVAL INSTRUCTIONS

Install instructions

Be sure the firearm is unloaded and pointed in a safe direction.

Install the handstop into the rail until it bottoms out on the first M-LOK slot.

Take the two install/removal tools and insert one in each M-LOK slot.

Press in on both sides and press towards the muzzle on the handstop.

It should snap into place on the second M-LOK slot.

To remove the handstop take the two install/removal tools and insert one into the second M-LOK slot on both sides.

Press down and slide them towards the muzzle making sure that the tool is pressed in all the way until you reach the top of the M-LOK slot . With the tools held in with one hand grab the handstop and pull it out. The handstop should easily slide out the front and if not make sure you are depressing the clamps that hold it in place.