



This area must be relieved in order for a standard AR15 pattern grip to clear the lower boss of the X-95 chassis. Both sides must be relieved symmetrically.

This can be done by carefully routing and/or sanding with a handheld rotary tool.

